# **QUANTI-Luc™** Gold

## A coelenterazine-based luminescence detection kit for standard and HTS assays

Catalog code: rep-qlcg1, rep-qlcg2, rep-qlcg5

https://www.invivogen.com/quanti-luc-gold

For research use only
Version 19F11-MM

## PRODUCT INFORMATION

#### Contents

QUANTI-Luc<sup>™</sup> Gold is a two-component reporter kit which contains:

- QUANTI-Luc<sup>™</sup> Plus, provided in individually sealed pouches
- QLC Stabilizer, provided in a tube

QUANTI-Luc<sup>™</sup> Gold is supplied in different formats:

- rep-qlcg1: 1 pouch of QUANTI-Luc<sup>™</sup> Plus and 1 tube of QLC Stabilizer
- rep-qlcg2:2 pouches of QUANTI-Luc™ Plus and 2 tubes of QLC Stabilizer
- rep-qlcg5:5 pouches of QUANTI-Luc™ Plus and 5 tubes of QLC Stabilizer

Each pouch provides sufficient reagent for  $5\times96$ -well plates (25 ml for standard procedure) or  $2\times1536$ -well plates (8 ml for high throughput screening (HTS) procedure). Each tube of QLC Stabilizer provides  $100~\mu$ l for the standard procedure (optional) or  $300~\mu$ l for the HTS procedure (required).

#### Required Material (not provided)

- Sterile water
- Sterile screw cap tube

#### Storage and Stability

- Store QUANTI-Luc™ Plus pouches at -20°C for 12 months.
- Store QLC Stabilizer at room temperature (15-25°C) for 12 months.
- Reconstituted QUANTI-Luc™ Gold is stable for 1 week at 4°C and for 1 month at -20°C. Prepare aliquots to avoid repeated freeze-thaw cycles.

  <u>Note:</u> This product is photosensitive and should be protected from light.

#### **Quality Control**

Each lot is thoroughly tested to ensure the absence of lot-to-lot variation.

- Physicochemical characterization (including pH, solubility).
- Functional assays using recombinant Lucia protein or reporter cells.

## **DESCRIPTION**

QUANTI-Luc™ Gold is an optimized kit for the detection of Lucia luciferase and other coelenterazine-utilizing luciferases (e.g. Gaussia and Renilla luciferases). This two-component kit comprises QUANTI-Luc™ Plus (coelenterazine-containing reagent) and QLC Stabilizer. The light signal produced is quantified using a luminometer and expressed as relative light units (RLUs).

This kit provides the user with two options for luciferase activity measurement (see Figure 1):

- (a) QUANTI-Luc<sup>™</sup> Plus without QLC Stabilizer allows enhanced light output detection (as compared to our standard QUANTI-Luc<sup>™</sup>).
- (b) QUANTI-Luc™ Plus with QLC stabilizer (QUANTI-Luc™ Gold) allows enhanced light signal stability (over 10 minutes). This option is ideal for HTS, time-course studies, or when using a luminometer without injectors.




Figure 1: Lucia luciferase activity detection with QUANTI-Luc<sup>™</sup>-based detection media. THP1-Dual<sup>™</sup> cells were stimulated for 24h with 10 µg/ml 2'3'-cGAMP. The ISG response was assessed by determining Lucia luciferase activity in the supernatant using QUANTI-Luc<sup>™</sup>, QUANTI-Luc<sup>™</sup> Plus, or QUANTI-Luc<sup>™</sup> Gold (QUANTI-Luc<sup>™</sup> Plus with QLC Stabilizer). Relative light units (RLUs) were measured over 10 minutes

## **METHODS**

QUANTI-Luc™ Gold has been optimized for use in 96-well plates (standard procedure) and in 1536-well plates (HTS procedure) as described below and on the next page.

## A. Standard procedure

Two options are available (see Figure 2):

- Option 1: for enhanced light signal stability, use QUANTI-Luc™ Gold (QUANTI-Luc™ Plus with QLC Stabilizer).
- Option 2: for enhanced light output detection, use QUANTI-Luc™ Plus alone.




Figure 2: Standard procedure using QUANTI-Luc  $^{\mathsf{TM}}$  Gold.



InvivoGen Europe: +33 (0) 5-62-71-69-39 InvivoGen Asia: +852 3622-3480 E-mail: info@invivogen.com

InvivoGen USA (International): +1 (858) 457-5873



#### Standard Procedure Option 1

- 1. Transfer the QUANTI-Luc™ Plus pouch contents into a 50 ml screw cap tube.
- 2. Add 25 ml of sterile water. Swirl **gently** until powder is completely dissolved
- 3. Add 100 µl of QLC Stabilizer.

Note: For optimal results it is important to add the correct volume, as too much QLC Stabilizer can result in decreased signal intensity.

- 4. Vortex **very briefly** (for a few seconds). Incubate at room temperature for at least 15 minutes.
- 5. Use QUANTI-Luc  $^{\!\scriptscriptstyle{\text{\tiny M}}}$  Gold immediately or store at 4°C or -20°C until needed.

 $\underline{\text{Note:}} \ \textit{This product is photosensitive and should be protected from light.}$ 

6. Proceed to measurement using one of the following protocols:

#### To obtain **end-point readings** using a luminometer **with an injector**.

- 1. Set the luminometer with the following parameters: 50  $\mu l$  of injection, end-point measurement with a 4 second start time and 0.1 second reading time.
- 2. Add 10-20  $\mu$ l of sample per well into a 96-well white (opaque) or black plate, or a luminometer tube.
- 3. Prime the injector with the QUANTI-Luc™ Gold assay solution and proceed **immediately** with the measurement.

#### To obtain **end-point readings** using a luminometer **without injectors**:

- 1. Set the luminometer with the following parameters: end-point measurement with a 4 second start time and 0.1 second reading time.
- 2. Add 10-20  $\mu$ l of sample per well into a 96-well white (opaque) or black plate, or a luminometer tube.
- 3. Add 50  $\mu l$  of QUANTI-Luc  $^{\!\scriptscriptstyle{\text{\tiny M}}}$  Gold assay solution to each well or tube.
- 4. Gently tap the plate several times to mix (do **not** vortex).
- 5. Proceed immediately with the measurement.

## Standard Procedure Option 2

- 2. Add 25 ml of sterile water. Swirl gently until powder is completely dissolved.

Note: This product is photosensitive and should be protected from light.

4. Proceed to measurement using one of the following protocols:

## To obtain **end-point readings** using a luminometer **with an injector**.

- 1. Set the luminometer with the following parameters: 50  $\mu$ l of injection, end-point measurement with a 4 second start time and 0.1 second reading time.
- 2. Add 10-20  $\mu l$  of sample per well into a 96-well white (opaque) or black plate, or a luminometer tube.
- 3. Prime the injector with the QUANTI-Luc™ Plus assay solution and proceed **immediately** with the measurement.

#### To obtain **end-point readings** using a luminometer **without injectors**.

- 1. Set the luminometer with the following parameters: end-point measurement with a 4 second start time and 0.1 second reading time.
- 2. Add 10-20  $\mu l$  of sample per well into a 96-well white (opaque) or black plate, or a luminometer tube.
- 3. Add 50 µl of QUANTI-Luc™ Plus assay solution to each well or tube.
- 4. Gently tap the plate several times to mix (do **not** vortex).
- 5. Proceed **immediately** with the measurement.

#### B. High Throughput Screening (HTS) procedure

The reading of a high throughput screening plate requires enhanced light signal stability. Therefore, we recommend to use QUANTI-Luc™ Gold (QUANTI-Luc™ Plus with QLC Stabilizer) for this assay.

This procedure has been optimized for use in HTS screening procedures in 1536-well plates. QUANTI-Luc™ Gold is added directly to the cell suspension to reduce liquid handling (see Figure 3).




Figure 3: High throughput screening procedure using QUANTI-Luc™ Gold.

- 1. Dispense cell suspension and test compounds into a 1536-well white or black plate in a volume that does not exceed 5  $\mu$ l per well. Incubate cells with test compounds for the desired period of time.
- 2. Transfer QUANTI-Luc™ Plus pouch contents into a 15 ml screw cap tube
- 3. Add 8 ml of sterile water. Swirl **gently** until powder is completely dissolved. Due to the small volume, this step may take several minutes.
- 4. Add 300 µl of QLC Stabilizer.

<u>Note:</u> For optimal results, it is important to add the correct volume as too much QLC Stabilizer can result in decreased signal intensity.

- 5. Vortex **very briefly** (for a few seconds). Incubate at room temperature for at least 15 minutes.
- 6. Use QUANTI-Luc™ Gold immediately or store at 4°C or -20°C until needed.

Note: This product is photosensitive and should be protected from light.

- 7. Dispense 2 µl of QUANTI-Luc™ Gold per wells containing ≤5 µl of cell culture in a 1536-well plate.
- 8. Record luminescence once the signal is stabilized according to your instrument setting.

## **RELATED PRODUCTS**

Product	Catalog Code
QUANTI-Luc <sup>™</sup> (secreted luciferase detection medium) Recombinant Lucia luciferase Protein	rep-qlc1 rec-lucia
Reporter Cells	
THP1-Dual™ (IRF-Lucia/NF-ĸB-SEAP) Cells	thpd-nfis
THP1-Lucia™ ISG Cells	thpl-isg
THP1-Lucia™ NF-ĸB Cells	thp1-nfkb

For a complete list of InvivoGen's Lucia luciferase Reporter Cell Lines visit <a href="https://www.invivogen.com/lucia-reporter-cells">https://www.invivogen.com/lucia-reporter-cells</a>

